



WIRES NOT FURNISHED WITH LAMP
(STATION WAGON ONLY)

TAIL AND STOP LAMP
(ALL MODELS EXCEPT
STATION WAGON AND
SEDAN DELIVERY)

TAIL, STOP AND
LICENSE PLATE LAMP
(STATION WAGON AND
SEDAN DELIVERY)

THESE WIRES NOT USED
ON STATION WAGON
AND SEDAN DELIVERY

THIS WIRE AND CON-
NECTOR USED FOR
ALL MODELS EXCEPT
STATION WAGON AND
SEDAN DELIVERY

LICENSE PLATE LAMPS
(ALL MODELS EXCEPT
STATION WAGON AND
SEDAN DELIVERY)

TAIL AND STOP LAMP
(ALL MODELS EXCEPT
STATION WAGON AND
SEDAN DELIVERY)

DOME LIGHT SW.
LH. DOOR
(DE LUXE SERIES)

DOME
LT. AND
SWITCH

DOME LIGHT SW.
R.H. DOOR
(DE LUXE SERIES)

NOTES:
WIRES INDICATED THUS --- ARE
FURNISHED WITH BODY.

ALL WIRES MARKED THUS ⊗ ARE NOT
A PART OF A WIRING HARNESS ASSEMBLY.
— ⊕ — INDICATES WIRE SPLICE.

ALL WIRES MARKED THUS ⊗ ARE
SUPPLIED WITH EQUIPMENT EXCEPT
AS NOTED.

Fig. 2—1950 Passenger Car Wiring Diagram